


### Vehicle Connection



1. Locate the data link connector(DLC) under the dash on the driver side of the vehicle.
2. Connect the diagnostic cable to the scanner and plug it to the vehicle DLC.
3. Switch the ignition key to the ON position.
4. Go to Main menu to choose diagnostic software to start test.

### Diagnostic Operations

- Before start diagnosis, please make sure:
  1. The ignition switch is turned to ON position.
  2. The engine is off.
  3. The vehicle battery voltage is between 10-14 volts.
  4. The scanner is correctly connected to the vehicle.
- Don't connect or disconnect the equipments while the ignition is on or the engine is running.

**1** Establish communication with the vehicle via diagnostic cable.

**2** Identify the vehicle either by VIN reading or entering vehicle specifications manually.


**3** Find the control modules installed in the vehicle either by Quick Scan or manual selection.

\* Select quick scan or manual selection if automatically read VIN not applicable to your car.

**4** Start the tests and make records of test data when necessary.

### Register and Update Via Client

Visit our site [www.foxwelltech.us](http://www.foxwelltech.us) and then click **Support** at the home page. Click **Tools** at the support page and find the product you have to download the update client.



Unzip the file and find the installer to install the update client to your computer.



Open the update client, click the register button, and follow the prompts to register for **FOXWELL ID**

Email

Verification Code  Send Code

Password

Confirm Password


Free Registration

Click "update" in the scanner after you connect the scanner via **USB** cable to your **PC**. Or Insert **SD** card via SD card reader (Recommend).




**USB & SD Card Reader**

Sign in your Foxwell account, and activate your diagnostic scanner after the FoxAssist automatically recognizes the serial number.



Select the car makes you want update and wait for the downloads until the process completed.



### To Print Test Results

Vehicle test results stored in the SD card can be printed through computer. Test data can only be imported to your computer through FoxAssist, it cannot be copied directly from the SD card.

- 1 Connect the scanner to the computer with the USB cable provided.
- 2 Launch the **FoxAssist** and log in with your Foxwell ID.
- 3 Click **Data Management** to view all the stored test results.
- 4 Choose the files you want to print and click **Print** button.

### Contact Us

For service and support, please contact us.

- WebSite : [www.foxwelltech.us](http://www.foxwelltech.us)
- E-mail : [support@foxwelltech.com](mailto:support@foxwelltech.com)
- Service Number : + 86 - 755 - 26697229
- Fax : + 86 - 755 - 26897226
- Amazon Support: [amazonsupport@foxwelltech.com](mailto:amazonsupport@foxwelltech.com)



REGISTER YOUR PRODUCT AT  
<http://www.foxwelltech.us/register.html>

### FAQs

Why does it prompt me that the serial number is invalid when I register this auto scanner? You may choose the wrong website.

- Please choose the correct website--[www.foxwelltech.us](http://www.foxwelltech.us).
- Or visit the link of the product directly, <https://www.foxwelltech.us/products.html>.
- Download the correct update tool--FoxAssist.

How to upgrade my obd2 device as fast as possible?

- Upgrade via card reader instead of USB cable.
- Uninstall the car diagnostic software that do not need. (Via the uninstall function of the FoxAssist.)
- Select software downloads in batches instead of all software during the upgrade process.

Did not receive the Verification Code?

- The verification code is sent to your email address automatically, please check your junk or Spam folder.
- If you have not received the email, please try to request the code again by clicking Send code at the registration page.
- Contact seller via Amazon message, and tell seller the serial number of your scanner.

Why can not I clear error codes & service light?

- To clear codes, make sure that the ignition key is switched to ON with the engine off.
- DTCs can only be erased after correcting the condition(s) that caused them.
- Erase Codes does not fix the problem that caused the fault! This is why you seem to cleared the fault light, but it turned on again soon.

Who do I contact if I have any questions about my order or scanner?

- Ask a question on the product page.
- Send a message via Amazon. (Recommend)
- Send us Email([amazonsupport@foxwelltech.com](mailto:amazonsupport@foxwelltech.com)).

Dear Customer,

Thanks very much for choosing Foxwell.

We've been working hard to ensure you are satisfied with our product. Any questions concerning your purchase detail (delivery, technical support, compatibility, return and refund assistance), please contact the seller - Obdzon first. They are professional enough and will try their best to help you out. A strong after-sales service and technical support team is standing by, please don't worry! If the scanner works well, we sincerely invite you to share your product experience on Amazon or your social platform. Your feedback will help us keep doing things right and making excellent products for you.

Yours sincerely,  
FOXWELL Support Team

